

Phase Manager v5 documentation



News

- **Version 5 release!**
 - What's new in V5

Features

- **Create phasing**
 - Introduction
 - Drawings management
 - GIS management
 - Areas and axes management
 - Print areas management
 - Tasks management
 - Connected objects management
 - The Gantt chart
- **Tasks**
 - The tasks management interface
- **Labels and areas conditions**
 - Areas conditions and labels management
- **Deliverables management**
 - Introduction
 - Deliverables management levels
 - The different types of deliverables
 - Creating deliverables
 - Copy and/or update a deliverable
 - Customizing deliverables
 - Managing statuses
 - Clipping drawings in deliverables
- **Page layout**
 - Creation of printing templates
- **Printing**
 - Printing deliverables
- **Calendars management**
 - Calendars management
- **File menu**
 - Import Export
 - Exporting the project's KML
 - Save project as a template
 - Archive a project
- **Options menu**
 - Project and Gantt properties
 - Labels management
 - User fields management

Follow the tutorial

- Step 1 : Creation of the drawings
- Step 2 : Adding areas and a first task
- Step 3 - Importing the project tasks
- Step 4 - Adding areas shapes to imported tasks
- Step 5 - Adding polyline
- Step 6 - Adding tasks to the polylines
- Step 7 - Adding tasks styles and page layout
- Step 8 - Creation and personalization of the phasing book

Ressources

- **Demo project explained**
 - Explore sample projects
 - GIS project
 - Clipping project
- **Sources**
 - Data source files (PMX, KML, project and data models)

FAQ

- **Best practices**
 - Key points when creating a phasing
- **Create phasing**
 - Unable to delete an unused drawing
- **Import / Export**
 - Links types not recognized when imported
 - Areas and axes duplicated after import
- **Légends**
 - Changing the Gantt's font size
 - Legends of areas : displays legends of status instead of my styles
 - How to resize the Gantt chart
- **Deliverables**
 - Blue stripes beyond the limits of the drawing
 - Map outside the limits of the print area is printed
 - Testing a layout : cannot create a deliverable
 - The order of objects is not functioning
 - Areas/axes/objects missing from the phasing book
- **Tasks styles**
 - Task styles not taken into account